

## Guidelines for Designing Your Shower

Consider the following questions before purchasing or installing an enclosure:

### **Have you measured all the dimensions and drawn a sketch of your bathroom and shower configuration?**

This helps us to provide you with the most appropriate solution for your bathroom needs.

### **What style of shower configuration are you considering?**

- Shower Door
- Tub Door
- Shower Enclosure
- Steam Door or Enclosure

### **Is there sufficient (i.e. greater than the door size) unused floor space in front of the shower to swing the door outward?**

### **Will the door swing open from the left or the right side?**

### **Is the tub or shower threshold sloped slightly in towards the drain so that water does not collect in these areas?**

### **Where will the plumbing fixtures be located in relation to the door of your enclosure?**

### **What glass type is preferred?**

Clear, opaque or a sandblasted design?

### **What color hardware would you desire?**

Brass, Chrome, Brushed Nickel, White, Other?

### **Is there a place to hang a towel within 12" of the shower?**

### **How long does it take to fabricate and temper the glass shower?**

It takes a couple of weeks to get the glass so be sure to get the measurements right, prior to ordering. Remember it is not possible to cut tempered glass if it is inaccurately cut the first time. A mistake in measurement will set you back at least 2 weeks.

### **What is the length of time to supply and install from time of measurement?**

Standard doors take approximately 3 – 10 days depending on scheduling. Custom enclosures take 14 business days for the tempering process.